


KNOTT Brake Assembly – Blow up Section



The above diagram is provided as a guide to the component parts and is not intended as an instruction for the replacement of component parts within a wheel drum. You are advised to seek qualified advice or assistance when replacing brake shoes or their associated parts

1	Brake Expander
2	Half Shell / Cable Guide
3	Eyelet
4	Shoe Spring
5	Brake Shoe
6, 7, 8	Adjustment Kit (Chocks, Wedge & Bolt)